

# Fertilizer Caddy®

## Fertilizer Injector

### Specifications

Model	Capacity	Inlet & Outlet	Minimum Required Flow Rate (GPM)	Gallons of Flow to Empty	Dimensions		
					Length	Width	Height
GMPC 7525	1½ Quart	¾" FPT x ¾" FPT	½	75	9"	5"	7"
GMPC 7525-H	1½ Quart	¾" FHT x ¾" MHT	½	75	9"	5"	7"
GMPC-1025	1½ Quart	1" FPT x 1" FPT	1	75	9"	5"	7"
GMPC 7550	½ Gallon	¾" FPT x ¾" FPT	½	100	1' - 0"	5"	7"
GMPC 7550-H	½ Gallon	¾" FHT x ¾" MHT	½	100	1' - 0"	5"	7"
GMPC 1050	½ Gallon	1" FPT x 1" FPT	1	100	1' - 0"	5"	7"
GMPC 75100	1 Gallon	¾" FPT x ¾" FPT	½	200	1' - 2"	8"	10"
GMPC 75100-H	1 Gallon	¾" FHT x ¾" MHT	½	200	1' - 2"	8"	10"
GMPC 10100	1 Gallon	1" FPT x 1" FPT	1	200	1' - 2"	8"	10"
GMPC 15100	1 Gallon	1½" FPT x 1½" FPT	2	200	1' - 2"	8"	10"
GMPC 20100	1 Gallon	2" FPT x 2" FPT	5	200	1' - 2"	8"	10"
GMPC 75200	2 Gallon	¾" FPT x ¾" FPT	½	400	1' - 10"	8"	10"
GMPC 75200-H	2 Gallon	¾" FHT x ¾" MHT	½	400	1' - 10"	8"	10"
GMPC 10200	2 Gallon	1" FPT x 1" FPT	1	400	1' - 10"	8"	10"
GMPC 15200	2 Gallon	1½" FPT x 1½" FPT	2	400	1' - 10"	8"	10"
GMPC 20200	2 Gallon	2" FPT x 2" FPT	5	400	1' - 10"	8"	10"
GMPC 75300	3 Gallon	¾" FPT x ¾" FPT	½	600	1' - 8"	10"	1' - 4"
GMPC 75300-H	3 Gallon	¾" FHT x ¾" MHT	½	600	1' - 8"	10"	1' - 4"
GMPC-10300	3 Gallon	1" FPT x 1" FPT	1	600	1' - 8"	10"	1' - 4"
GMPC 15300	3 Gallon	1½" FPT x 1½" FPT	2	600	1' - 8"	10"	1' - 4"
GMPC 20300	3 Gallon	2" FPT x 2" FPT	5	600	1' - 8"	10"	1' - 4"
GMPC 75500	5 Gallon	¾" FPT x ¾" FPT	½	1,000	2' - 2"	10"	1' - 4"
GMPC 75500-H	5 Gallon	¾" FHT x ¾" MHT	½	1,000	2' - 2"	10"	1' - 4"
GMPC 10500	5 Gallon	1" FPT x 1" FPT	1	1,000	2' - 2"	10"	1' - 4"
GMPC 15500	5 Gallon	1½" FPT x 1½" FPT	2	1,000	2' - 2"	10"	1' - 4"
GMPC 20500	5 Gallon	2" FPT x 2" FPT	5	1,000	2' - 2"	10"	1' - 4"
GMPC 751000	10 Gallon	¾" FPT x ¾" FPT	½	2,000	4' - 4"	10"	1' - 4"
GMPC 751000-H	10 Gallon	¾" FHT x ¾" MHT	½	2,000	4' - 4"	10"	1' - 4"
GMPC 101000	10 Gallon	1" FPT x 1" FPT	1	2,000	4' - 4"	10"	1' - 4"
GMPC 151000	10 Gallon	1½" FPT x 1½" FPT	2	2,000	4' - 4"	10"	1' - 4"
GMPC 201000	10 Gallon	2" FPT x 2" FPT	5	2,000	4' - 4"	10"	1' - 4"

FPT - female pipe thread

FHT - female hose thread

MHT - male hose thread

A minimum of 10 PSI (pounds per square inch) of pressure is required for the injector to function. The inlet/outlet of the injector must be installed higher than the additive tank.

Care must be taken to ensure that anything that is placed into the fertilizer tank cannot flow back into the potable water system. An approved backflow device such as an anti-siphon valve, a pressure vacuum breaker, or reduced pressure backflow preventer, must be installed upstream from the fertilizer injector.

Fertilizer must be in liquid form when it's poured into the injector. If using a premixed liquid, you can pour it in full strength. If using dry, totally water soluble granular fertilizer, such as Scotts Miracle-Gro® or Peters Professional®, premix with water.

**Never** pressurize the injector without it being completely full of water, fertilizer, or additive! **Never** install the injector in direct sunlight! **Always** drain unit if there is a chance of freezing!

## Strong Injectors™

A Division of Strong Enterprises

308 Melville Court, Roseville, CA 96747

(916) 797-1056 phone/fax • addit123@aol.com • <http://www.fertilizerdispensers.com>

**A Leading Manufacturer of Proportioning Fertilizer Injectors for the Irrigation Industry!**